

FORBES
&
LOMAX



THE PAINTED RANGE

The Painted Range provides primed ready-to-paint plates that sit flush to the wall. Each plate can be painted onsite to match the wall color, for a subtle and unobtrusive look. Plates are available with Toggle Switches, Rotary Dimmers, or Push Buttons. These switch components are supplied in your choice of Unlacquered Brass, Brushed Brass, Nickel Silver, Stainless Steel, or Antique Bronze. Painted Outlets are also available to complement the switch plates.

Painting instructions: Lay the plate on a flat surface (a piece of clean paper is ideal). Using a small roller, apply two to three coats of paint. If desired, a clear matte varnish can be used as a top coat to protect against marks and blemishes. Ensure the plate is completely dry before installing. Please note: plates can be rolled, hand-painted, or sprayed – each type of paint application will yield a different look. For outlet plates, the heads of the screws can be painted to match.

Junction boxes must be recessed below the finished wall surface by at least 1/8". See our Junction Box Assembly Diagram [technical sheet](#). Technical sheets are available from the [Technical Section](#) of our website.

AVAILABLE WITH

TOGGLES
ROTARY DIMMERS
PUSH BUTTONS
OUTLETS

Toggles, Rotary Dimmers, Push Buttons and Outlets can be mixed on the same plate.

Multi-gang plates can be supplied to accommodate as many devices as required. See our [Plate Dimensions](#) technical sheet.

ussales@forbesandlomax.com | www.forbesandlomax.com